### **ABUS** Security-Center



FUBE50020

## **Proximity Chip Key**

The proximity key is an optional accessory for contact—free arming and disarming of alarm panels, replacing code entry. It allows unique authentication of the user in the alarm system.

#### Easy operation:

To arm or disarm the system, you just hold the chip in front of the alarm panel or control panel. The user no longer needs to remember a PIN code, and this makes authorization (authentication) on the system much easier. It is used for easy, convenient arming and disarming of the ABUS alarm systems Secvest 2WAY and Terxon.

#### Installation and programming:

The chip key is trained into the alarm panel; the authorization is then programmed directly at the alarm panel. The radio field of the receiver provides the voltage to the proximity key for the code transmission; the key does not need its own battery.



#### **Product highlights:**

- For arming/disarming the Secvest 2WAY and Terxon
- Without code entry never "forget your PIN code" again
- · Simply hold in front of the alarm panel or control panel
- Functions on a completely contact-free basis
- · Several chip keys can be trained

### **ABUS** Security-Center



FUBE50020

# **Proximity Chip Key**

#### **Technical Data**

Dimensions

(HxD) 7,5x34 mm